

NOTE: REMOVE THE "YELLOW/RED" WIRE FROM THE BRIDGE RECTIFIER TO TERMINAL BLOCK #10.

INSTALL "YELLOW/RED" WIRES FROM "LOW TEMP SHUTDOWN" AS SHOWN .

