

BLACK 3 PHASE

RED 3 PHASE

BLUE 3 PHASE

SAFETY IN

FORWARD

REVERSE

END TOWER

END GUN

WHITE - NEUTRAL

GREEN/ YELLOW - GROUND

CC = CONTACTOR COIL

M/S = MICROSWITCH

DS = DISCONNECT SWITCH

